

**INSTALLATION METHOD FOR ALTERNATOR BRACKET**  
**PCE232.1032**



## BEFORE INSTALLING

Before PCE232.1032 is installed, the old alternator bracket needs to be removed. While the alternator bracket is off, clean the area.

## INSTALLATION PROCESS

**NOTE:** Apply small amount grease to the tie rods threads and rod ends prior to installation. Install the rod ends into the rod to make the tie rod.

**NOTE:** The alternator will be placed in the area where the power steering pump is located when using PCE232.1032.

See the following drawing:

