# INSTALLATION METHOD FOR FORD C4 FULL MANUAL REVERSE VALVE BODY

## PCE634.1004 Series



**NOTE:** Read instructions completely before attempting installation. This valve body should be installed by a qualified transmission technician. If you are unfamiliar with any of the operations or terms found in these instructions, you should take the transmission to a qualified race transmission shop. Improper installation may result in property damage or personal injury.

**CAUTION:** Before any further actions take place, make sure transmission has had enough time to cool down. Hot transmission fluid can result in burns.

## **REMOVAL PROCCESS**

- 1. Drain the transmission fluid by removing the oil pan drain plug.
- 2. Remove the oil pan by removing the oil pan bolts.

**NOTE:** If the dipstick is attached to the pan, the dipstick removal will allow oil to drain out.

3. Remove the eight (8) valve body bolts and remove the valve body.

#### INSTALLATION PROCCESS

1. Install the transbrake valve body into the transmission.

**NOTE:** You must engage the selector lever into manual valve. The transmission will now become fully manual and kickdown lever is now unused.

- 2. Evenly tighten the valve body finger tight. Make sure shifter linkage can operate freely. Then tighten valve body bolts to 70-80 in. lbs.
- 3. Remove excess gasket material from pan mounting area of the case and from the pan itself.
- 4. Tighten the pan bolts to 10-14 ft. lbs.

## **ADJUSTMENT PROCCESS**

**NOTE:** The shifter adjustment must be checked.

**DANGER:** Do not skip this process.

**CAUTION:** Shifter must not be allowed to pull transmission shift linkage past the detent for the HIGH gear (3<sup>rd</sup> gear). Shift arm on transmission must not travel past the last full detent.

## TRANSMISSION FLUID

- 1. Add three quarts of DEXRON or Type-F transmission fluid.
- 2. Start the engine and put the vehicle in neutral.
- 3. Check the fluid level and add fluid until it is at the "ADD" mark found on the dipstick.
- 4. Shift through all the gear positions five (5) times.

**NOTE:** Test transbrake at this moment.

5. Check fluid level again and fill to "FULL"

**CAUTION:** Transbrake must not be engaged while the vehicle is in motion.